



- 1 ▶ INSTALL 1-#1 1/0 AL T.P TEMPORARY ON GROUND IN FLEX CONDUIT FROM PEDESTAL OR TRANSFORMER TO METER BASE ON HOUSE.
- 2 ▶ DISCONNECT EXISTING SERVICE FROM HOUSE IN METER BASE & CONNECT TEMPORARY FEED IN TRANSFORMER OR PEDESTAL.
- 3 ▶ BORE 1-2" POLY CONDUIT FROM PEDESTAL OR TRANSFORMER IN SERVICE EASEMENT TO BORE PIT PERPENDICULAR TO METER BASE. ALL SOIL CONDITIONS.
- 4 ▶ HAND DIG TRENCH FROM BORE PIT IN EASEMENT TO METERBASE LOCATION AND INSTALL 1-2" POLY CONDUIT TO METER BASE. ALL SOIL CONDITIONS.
- 5 ▶ PULL IN 1-#1 1/0 AL T.P SERVICE IN NEWLY INSTALLED CONDUITS TO METER BASE.

- 6 ▶ MAKE UP CONNECTIONS IN METER BASE AFTER DISCONNECTING TEMPORARY.
- 7 ▶ CONNECT 1-#1/0 AL T.P. SERVICE IN TRANSFORMER OR PEDESTAL
- 8 ▶ CHECK & DOCUMENT VOLTAGE AT METER BASE BY ADDRESS

NOTE: THESE SERVICES ARE TO BE INSTALLED
 IN 2" PVC CONDUIT AT A DEPTH OF 36".
 SEE STANDARD UG-2425

TITLE TYPICAL SINGLE SERVICE INSTALLATION "EXHIBIT A"		 Garland Power & Light	DESIGNED BY: J.BODINE	DATE: 8/18/06
SCALE: NTS	REVISED BY: JC DATE: 2/13/11 APPROVED BY: DM		DRAWN BY: J.CARRILLO	DATE: 8/18/06